




# Microsoft Band 2 Battery Replacement

Removing the Microsoft Band 2 battery

Written By: Chris Syracuse



## INTRODUCTION

This guide will show you how to remove the Microsoft Band 2 battery in case the battery dies out, a common problem in the Band 2.


---



### TOOLS:

- [T3 Torx Screwdriver](#) (1)
  - [Metal Spudger](#) (1)
  - [iFixit Opening Tools](#) (1)
  - [Tweezers](#) (1)
-

## Step 1 — Battery



- Peel back the metal cover on the end of the watchband.

## Step 2



- Use a T3 Torx screwdriver to unscrew the four 6 mm screws on the corners of the metal cover plate.





## Step 3





- Use the plastic opening tool to pry off the metal cover plate.

## Step 4




- Detach the black ribbon cable by using the tweezers.

## Step 5



- Detach the orange press-fit (or "pop") connector by using the tweezers.

## Step 6



- Pry out the battery using the plastic opening tool.

To reassemble your device, follow these instructions in reverse order.

